

## For AirCell® Radiating Double Jacketed Cables

**3D**

For Use with AirCell Instruction sheets 3, 3A, 3B, and 3C

### General Description

AirCell® connectors are designed specifically for use with Trilogy's AirCell® 50 Ohm Transline and Radiating cables. **Instructions should be read thoroughly prior to connector installation.**

### Installation Tools

Razor Knife

Degreasing Solution

### Prepare Cable for Connectorization

- 1) Remove 5" of the outer cable jacket from the cable end using the razor knife.
- 2) Use the degreasing solution to remove the jacket lubricant from the outside of the inner-jacket.
- 3) Refer to appropriate connectorization instructions for the cable prep tool and connector to be installed (Instruction Sheets 3, 3A, 3B, and 3C).

Notice: Trilogy disclaims any liability or responsibility for the results of improper or unsafe installation, inspection, maintenance, or removal practices.